





ELOTECH
INDUSTRIELELEKTRONIK

R4100

Controller for Temperature Control Systems



DESCRIPTION AND OPERATING MANUAL

ELOTECH Industrieelektronik GmbH
Verbindungsstraße 27
D - 40723 HILDEN
Phone +49 2103 / 255 97 0
www.elotech.de

Fax +49 2103 / 255 97 29
Email: info@elotech.de

Table of Contents

Table of Contents	2
1 General Information	3
2 Installation Instructions	3
3 Type Codes	5
3.1 Type Code of Controller	5
3.2 Type Code of IO-Board	5
4 Connection Diagrams	6
4.1 Connection Diagram IO-Board	6
4.2 Connection Diagram Controller	6
4.2.1 Connection Diagram Fieldbus Modules	7
4.2.2 Connection Diagram: LAN and USB	7
5 Operating the device	8
5.1 General advises regarding GUI	8
5.1.1 Entry of numerical values	8
5.1.2 Activate / deactivate functions	9
5.1.3 Handling of listings	9
5.1.4 Entry of text	10
5.1.5 Menue layout	11
5.2 Menues	12
5.2.1 Operating Mode display (Home)	12
5.2.2 Main Menue	13
5.2.3 Menue „Functions“	14
5.2.4 Menue „Process“	16
5.2.5 Menue „Pump“	16
5.2.6 Menue „Alarms“ (Event Monitoring)	17
5.2.7 Menue „Alarm Log“	19
5.2.8 Menue „Graph“	20
5.2.9 Menue „Program“ (Program controller graph)	20
5.2.10 Menue „Parameters“	24
5.2.11 Menue „System“	28
6 Error Messages	33
7 Technical Data	34

1 General Information

Symbols used:

www.elotech.de	Messages shown by the controller are written in this font.
MRS / MRE	Measuring Range Start / Measuring Range End
<Default>	Symbolizes the factory adjustment of the respective parameters.

2 Installation Instructions

Make sure the device is used for the intended purpose only.

The devices of type R4100-C are designed for installation in control panels, the I/O-Boards of type R4100-M are designed to be mounted on cap rails.

Protect the device against impermissible humidity and contamination.

The permitted ambient temperature range may not be exceeded.

Electrical connections must be made according to valid regulations and by properly qualified personnel.

If using thermocouple sensors, compensation lines have to be connected directly to the controller terminals. Sensors may be connected only in compliance with the programmed range.

Sensor cables and signal lines (e.g. logic or linear voltage outputs) must be placed separately from control lines and mains voltage supply cables (power cables).

In order to maintain EMC compliance screened detectors - and signal lines have to be used.

It is not permitted to connect the grounds of the sensor-inputs and logic-outputs with each other.

Spatial separation of R4100 devices and inductive loads is recommended. Interference from contactor coils must be suppressed by connecting adapted RC-combinations parallel to the coils. Control circuits (e.g. for contactors) should not be connected to the mains power supply terminals of the R4100 devices.

The configuration parameters (Window: System) are generally to be selected first.

Disclaimer of Liability


The contents of this document is checked for the conformity with the hardware and software described. Nevertheless, we are unable to preclude the possibility of deviations so that we are unable to assume warranty for full compliance. However, the information given in the publication is reviewed regularly. Necessary amendments are incorporated in the following editions.

We would be pleased to receive any improvement proposals which you may have.

The information contained herein is subject to change without notice.


Disposal

Electronic scrap and components are subject to special treatment and must be disposed of by authorised companies.




3 Type Codes

3.1 Type Code of Controller




3.2 Type Code of IO-Board




4 Connection Diagrams

4.1 Connection Diagram IO-Board




4.2 Connection Diagram Controller




4.2.1 Connection Diagram Fieldbus Modules

Serial Interface



The serial fieldbus module contains the three interfaces RS232, RS485 and TTY. By choosing **the connection and setting the parameter "HW-config"** the requested bus is selected.

Typ 09: Profibus



The 5V-Supply is designed for the supply of the termination resistors. Further loads are not allowed.

4.2.2 Connection Diagram: LAN and USB

USB:

- Save process data, configuration data and alarm data on an USB-Stick.
- Write back configuration data from USB-Stick to the controller.
- Make a Firmwareupdate. (Please use FAT formatted USB flash drives.)

LAN:

- Connection to configuration tool Elovision 3.
- Read and write parameters by MODBUS-TCP protocol
- Webinterface for easy configuration

5 Operating the device

5.1 General advises regarding GUI

The device R4100-C provides a high-contrast color screen with touch functionality.



After switching on the devices R4100-C and R4100-M and after completion of the initialization, the actual temperature value and the setpoint are displayed.

The device R4100-C is operated by menus. The different parameters are displayed mainly in plain text and can be displayed in English and German language.






In the following the general methods of data and commands entry are explained:

5.1.1 Entry of numerical values



	<p>The header displays on the left the current adjustable parameter (this example: setpoint 1)</p> <p>By pressing the number keys the value of the parameters can be entered.</p> <p>By pressing the "SAVE"- key the entered value will be set.</p>
	<p>The value, entered by pressing the number keys, is displayed within the blue frame.</p> <p>Underneath, on the left the unit is shown and the previous value is displayed on the right (250).</p> <p>The allowed range is displayed at the bottom (0...800).</p>
	<p>If this Button is visible, two adjustable parameters are available. Such as: upper limit / lower limit or rising ramp / falling ramp Switch over by pressing this button. The name of the actually adjustable parameter is displayed in the header. After adjusting one parameter the window will not be closed and the second parameter can be adjusted.</p>
	<p>This key is visible when the parameter has a valid value "OFF". "OFF" can be selected like a number key.</p>
	<p>Number key</p>
	<p>Key to enter "Minus" or "Comma". The minus sign can be pressed before entering a number. After the first number was entered the key automatically changes to comma.</p>
	<p>Delete last character</p>


	Return to previous window
	Saving of entered data and returning to previous window

5.1.2 Activate / deactivate functions









	<p>By pressing the tile key, the function can be selected.</p> <p>Black text on a white background is used to display the selected element.</p> <p>In order to activate the selected function, the "SAVE"-key needs to be pressed.</p>
	Selected element: Black text on a white background
	Element not selected: White text on a blue background
	Saving of selection and return to previous window
	Return to previous window

5.1.3 Handling of listings


	<p>The header displays the name of the listing, here "Parameter".</p> <p>The currently selected submenu is displayed in the middle with light blue background. In order to open the selected submenu please press on the tile.</p> <p>By pressing the +/- Buttons on the right (or pressing the upper or lower areas of the list) the list can be slided up or down.</p>
	Jump to menu „Main“

	Return to previous window
---	---------------------------

5.1.4 Entry of text











	<p>Particular elements can be provided with names.</p> <p>By pressing the number keys „0 ... 9“ the new text can be entered. To set the following letters “ABC1” you have to press the key more times.</p> <p>After one second the character is taken over and the next character can be entered.</p> <p>In order to take over the new text, it must be saved by pressing the “SAVE”– key.</p>
	<p>The entered text is displayed in the blue/white frame.</p>
	<p>Delete last character.</p>
	<p>Delete all characters.</p>
	<p>Key for setting the text. Repeated pressing changes to the next character. Here "A B C 2 Ä"</p>
	<p>Switching case sensitive. Capital and small letters.</p>
	<p>Return to previous window</p>
	<p>Saving of the new text and return to previous window.</p>

5.1.5 Menue layout














5.2 Menues

5.2.1 Operating Mode display (Home)





	
	<p>Button „Menue“: Jump to Main Menue</p>
	<p>Button „Alarm Log“: Jump to the record of events including the temperature alarms</p>
	<p>Button „on / off“: By means of the button represented on the left hand side the temper device will be switched on / switched off. The colour indicates the actual result of pressing the button: Green: The device will be switched on Red: The device will be switched off.</p>
	<p>Actual temperature value Touch on this section: Jump to setpoint menu</p>
	<p>Setpoint Touch on this section: Jump to setpoint menu</p>
	<p>Example of status display</p> <ul style="list-style-type: none"> • device on, controller running • pump is running • heating output is on
	<p>Jump to Main Menue</p>
	<p>Jump to menue „Parameters“</p>
	<p>Jump to menue „Graph“</p>

5.2.2 Main Menu

	<p>This menu provides the access to the menus and displays</p>
	<p>Jump to the Operating Mode display. Shows actual temperature, setpoint, activity of heater and cooler outputs</p>
	<p>Jump to menu „Process“ Listing of setpoint, actual values of forward circulation temperature and circulation return temperature, output ratio of heater (if leading sign is positive) respectively output ratio of cooler (if leading sign is positive).</p>
	<p>Jump to menu „Graph“ Diagram of the actual temperature value of the controlled temperature (forward / return)</p>
	<p>Jump to menu „Functions“</p> <ul style="list-style-type: none"> • Activation of autotune • Activation of cooling down and switch off • Activation of tool (equipment) drainage • Selection of setpoint 1 or setpoint 2 • Selection of target of temperature control (supply or return) • Selection of filling mode (manual filling or automatic filling) <p>Details see 5.2.3</p>
	<p>Jump to menu „Alarms“ (Configuration of event monitoring) By means of this menu the automatic signaling of events (generally out-of-band signaling) can be determined. Details see 5.2.6</p>
	<p>Jump to menu „Pump“ Configuration: Automatic / manual / Cleaning Details see 5.2.5 <i>(prospective feature – currently not available)</i></p>
	<p>Jump to menu „Parameters“ Details see 5.2.10</p>

	<p>Jump to menue „Program“ By means of this menue temperature-time-profiles, which are more complex than simple temperature ramps, can be set up. Details see 5.2.9</p>
	<p>Jump to menue „System“ System configurations: date, time, data rate, authorizations Details see 5.2.11</p>
	<p>Touch < 2 seconds = jump to preceeding display Touch > 2 seconds = jump to operating mode display</p>

5.2.3 Menue „Functions“

	
	<p>Function „Autotune“ please see chapter 5.2.3.1</p>
	<p>Function „Cooling and off“</p> <ol style="list-style-type: none"> 1. Cooling valve open (-100 %) 2. Device will be switched off as soon as temperature is below „cool down temperature“ (see menue 5.2.10.5)
	<p>Function „Drainage“ (of tool equipment). This function makes the pump run reverse and opens the drainage valve.</p> <ol style="list-style-type: none"> 1. Cooling down to „cool down temperature“ (see menue 5.2.10.5) 2. Reverse pump direction 3. Drainage: Wait delay „drainage time“ (see menue 5.2.10.7) 4. Switch off device <p>The stage „Cooling down“ can be aborted by switching off the device. The stage „Drainage“ can not be aborted. The device shows error message.</p>


<p style="text-align: center;">Filling manually</p>	<p>Function „manual / automatic filling“:</p> <p>If the button „Filling“ is toggled to „automatic“: The filling valve will be activated if the filling level drops below maximum level.</p> <p>If the fluid level is on maximum level (both contacts closed) the pump will be released. If the fluid level is inbetween maximum and minimum level the pump remains released.</p> <p>If the fluid level drops below minimal level (tank empty) the pump will be locked.</p> <p>When filling (tank is empty) was activated the pump will not be released until the fluid level exceeds maximum level.</p> <p>If the filling procedure lasts longer than „maximal filling time“ (see menu 5.2.10.6) the the alarm output is activated.</p>
<p style="text-align: center;">Selection Setpoint 1</p>	<p>Selection of setpoint 1 / setpoint 2:</p> <p>Dependent on the current selection the controlled temperature follows setpoint 1 or setpoint 2.</p> <p>If setpoint 2 is selected the operating mode display shows „SP2“ at the headline.</p>

5.2.3.1 Autotune


<p style="text-align: center;">Autotune off</p>	<p>off</p>	<p>Switches off autotune <Default></p>
	<p>on</p>	<p>Activates autotune</p>
<p>The tuning algorithm determines the characteristic values within the controlled process and calculates the valid feedback parameters (P, D, I) and the cycle time. (= 0.3 x D) of a PD/I- controller for a wide section of the range.</p> <p>The autotune mode works during start-up shortly before the setpoint is reached. If activated after the setpoint has already been reached, the temperature will first drop by approx. 5% of the measuring range.</p> <p>The tuning algorithm can be activated at any time by selecting the parameter Autotune = "on". After having calculated the feedback parameters, the controller will lead the process value to the actual setpoint.</p> <p>Selecting Autotune = "off" will stop the autotune function.</p> <p>Autotune duration > 2 hours: autotune stops with an error message.</p>		

Conditions for starting the autotune algorithm:

- The setpoint must amount to at least 5% of the measurement range
- The sensor must not have a failure.
- The softstart function must not be active




OPT on
self tune during start-up



OPT on
self tune, after the setpoint has
already been reached


5.2.4 Menue „Process“



This display shows the fundamental current process values

- Setpoint of the controlled temperature
- Actual value of the controlled temperature
- Actual value of the recirculation
- Actual value of the external temperature
- Actual output ratio
 - positive sign means heating
 - negative sign means cooling

5.2.5 Menue „Pump“



General behaviour:

- The pump works with clockwise rotation, if
- the temper device is in stage „power on“
 - the filling level regulation has released the pump
 - the motor protection is not active

(The pump configuration menu pictured on the left hand side is a prospective feature – currently not available)

5.2.6 Menue „Alarms“ (Event Monitoring)

	<p>Explanations to the submenus pictured on the left hand side please find as follows in paragraphs 5.2.6.1 and 5.2.6.2.</p>
--	--

5.2.6.1 Menue „Configuration Monitoring“

	<p>By means of this menu the events can be determined which shall generate signals and messages:</p> <ul style="list-style-type: none"> • out-of-band of the supply (forward circulation) temperature • out-of-band of the supply (forward circulation) temperature • out-of-band of the supply (forward circulation) temperature • restart was locked after power-on <p>Furthermore the switching behaviour of the event monitoring relay can be determined:</p> <ul style="list-style-type: none"> • „Direct“: the contacts are closed when event is active • „Inverse“ the contacts are open when event is active
--	--

5.2.6.2 Configuration of temperature monitoring

The image shows three screenshots of the device's alarm configuration interface. Each screenshot displays the configuration for a specific alarm type: Supply alarm (T12), Return alarm (T13), and External alarm (T14). The interface is organized into a grid with the following fields:


- Alarm values:** OFF / OFF
- Type:** Absolute
- Delay:** OFF
- Start Suppression:** OFF

Each screenshot also includes a back arrow icon and a grid icon at the bottom left.






The device provides the monitoring of the following 3 temperature readings:

- supply temperature (temperature of forward circulation)
- return temperature (temperature of return circulation)
- externally measured temperature

The monitoring of the readings listed above can be adjusted as follows:

- lower limit value
- upper limit value
- **absolute limits:** if „absolute“ is activated the limits are not dependent on the set point
- **relative limits:** if „relative“ is activated the limits are dependent on the set point value. The complete limit values are then figured out, e.g.:
 Upper limit = 80 °C Setpoint + 10 Kelvin (upper limit value) = 90 °C
 Lower limit = 80 °C Setpoint - 10 Kelvin (limit value) = 70 °C
- the alarm signalization is delayed about the entered time (1...8000 s)
- start-up suppression: If activated the  -Alarm is not released until the temperature will have attained once the inner-band sector.

5.2.7 Menue „Alarm Log“

	<p>This listing saves significant events (Power On, temperature alarms, lock on restarts)</p> <p>The headline shows the current date, time and current page of log listing.</p> <p>If you push and hold a particular entry it will appear in full length.</p> <p>If you push the underpart of the listing the log is scrolled on.</p> <p>The log listing is able to save up to 40 event entries. The most recent entry is listend on page 1/5. If there are more than 40 entries the first input will be deleted.</p> <p>The log listing is stored mains failure safe.</p>
	<p>Jump from operating mode display to the log listing</p>
	<p>Page up / page down „+“ preceding page; „-“ next page</p>
	<p>Jump back to the operating mode display</p>
	<p>Clear log listing</p>

5.2.8 Menue „Graph“

This window shows the temperature curve.

In the case of a technical incident the actual process value can still be examined afterwards.



	<p>On the right the actual process value is shown, here 250°C.</p> <p>By pressing the zoom keys "+" and "-" the resolution of the temperature axis can be altered.</p> <p>The time axis can be determined by the parameter "Graph sampling time" in the window "System/Settings".</p> <p>Turning off the device causes deletion of the values.</p>
	<p>Hold down < 2 sec. = Return to previous window Hold down > 2 sec. = Jump to window "Operating Mode Display"</p>
	<p>Jump to main menu</p>

5.2.9 Menue „Program“ (Program controller graph)


	<p>The header displays the current program, the current step and the status.</p> <p>Right above the graph is the indication of the current program setpoint.</p> <p>At the bottom (x-axis) the time is shown in hours.</p> <p>The elapsed time is displayed as a blue ribbon.</p> <p>The current time is indicated by the thin vertical blue line.</p>
	<p>By means of these keys the program is controlled:</p> <ul style="list-style-type: none"> • Start • Pause • Stop • Edit (only available in mode "Stop")
	<p>Hold down < 2 sec. = Return to previous window Hold down > 2 sec. = Jump to window "Operating Mode Display"</p>

5.2.9.1.1 Setting of program controller

The button "Edit" opens the program set up menu:


Select the program		
	<p>The green frame shows the selected program. Select a other program by pressing + and – keys.</p> <p>Press the respective program button branches to the setup menu of the program.</p>	
Setting program properties		
		
Continue if	Time expired	All steps are executed according to the time grid entered in the appropriate step menu.
	Temp. reached	After the time has elapsed, the controller switches to the next step. The step setpoint must be reached up to + - 2K.
Program end	setpoint 1	After completion of the last step, the current setpoint is set active. Normally setpoint 1.
	Last setpoint	After the last step has been completed, the temperature of the last step is further regulated.
	Repeat	After the last step has been completed, step 1 is started again.
Number of steps	1 ... 8	Number of steps
Name		Entry of the program name

Setting step properties




Here the set up menu of the particular step can be invoked.

Setting the step parameter



In this figure, the ramp duration, the step temperature and the dwell time can be set for the particular step.



The key S1 + selects the next step.




The key S1 - selects the previous step.

Ramp duration	0:00 ... 99:59h	Time setting in which the setpoint shall move from the previous step temperature to the setpoint of the current step. In the first step, the actual value is set as the start setpoint. * If no ramp is desired, set this time to 0: 00h.
Temperature	-100 ... 1600°C	Temperature (setpoint) of this step.
Dwell time	0:00 ... 99:59h	Hold time of the current step temperature (step set-point). The dwell time starts after the end of the ramp duration. If configuration is switched to "temp. reached" , this time does not start until target temperature of the particular step is attained.


Program status in operating mode display (headline)

°C	↶ 2 ▶ ↘-1 ↙-2 12:34	Program controller active, Step2 is running.
°C	↶ 2 ↘-1 ↙-2 12:43	Program paused or stopped


5.2.10 Menue „Parameters“

	<p>By means of this menu the configuration of all controller-related parameters can be set up.</p>
	<p>Hold down < 2 sec. = Return to previous window Hold down > 2 sec. = Jump to window "Operating Mode Display"</p>
	<p>Jump to main menu</p>

5.2.10.1 Tool (equipment) selection

	<p>It is possible to store and to select 8 different sets of particular controlling parameters. Affected are the parameters being part of the submenus „Heating“, „Cooling“ and „Configuration Heating / Cooling“.</p> <p>If tool no.4 is selected, e.g., the parameter set no.4 is applied to the temperature controlling. This parameter set is then also accessible for adjusting.</p> <p>If tool no. 2 – no. 8 is selected in the headline of the Operating Mode Display the no. of the current tool parameter set is indicated: „W.4“, e.g.</p> <p>If the standard parameter set (no. 1) is selected there is no tool identification displayed.</p>
---	--

5.2.10.2 Configuration Heating / Cooling

	<p>Heating <Default></p>	<p>Two-point controller: "Heating"</p>
	<p>Cooling</p>	<p>Two-point controller: "Cooling"</p>
	<p>Non-lin. Cooling</p>	<p>Two-point controller: "Cooling" , with non-linear characteristic curve for evaporation cooling</p>
	<p>Heating-Cooling</p>	<p>Three-point controller: "Heating-Off-Cooling"</p>

5.2.10.3 Control Parameters

By default the controller operates in PD/I control mode, i.e. controlling without deviation and with nearly no overshoot during start-up.
The controlling behaviour can be changed by adjusting the PID parameters listed in paragraphs 5.2.10.3.1 and 5.2.10.3.2:

no feed back	Setting P = off (then D and I are switched off as well)
P-controller	Setting D and I = off
PD-controller	Setting I = off
PI-controller	Setting D = off
PD/I-controller	Modified PID-mode (set: P,D,I)

5.2.10.3.1 Heating Control Parameters

Heating Control parameter		This menu is only available if configurations Heating oder Heating-Cooling is selected. Depending on the configuration, parti-cular parameters are not visible.
P (xp)	OFF, 0.1 ...400.0K <Default=10,0>	Proportional range Unit: Kelvin
D (tv)	OFF, 1 ... 200s <Default=30s>	Derivative time
I (tn)	OFF, 1 ... 1000s <Default=150>	Reset time
Cycle-time	0.5 ... 240.0s <Default=10,0s>	The switching frequency of the actuator can be determined through the cycle time. In this time interval the controller switches on and off once. <u>Voltage outputs for solid state relays (SSR):</u> Cycle time: 0,5...10 s Preferred settings for rapid control processes: 0,8s <u>Relay outputs:</u> Cycle time: > 10 s The cycle time should be adjusted to a time as long as possible in order to minimize wear of the relay contacts.
Max. Output ratio	0 .. 100% <Default=100%>	The limitation of the output ratio is only necessary, if the heating energy supply is grossly overdimensioned compared to the power required. Normally it should be switched off (Setting: 100 %). The limitation becomes effective when the controller´s calculated output ratio is greater than the maximum permissible (limited) ratio. Warning! The output ratio limiting does not work during autotune.
Hysteresis	Only adjustable if "(xp)" = off (on-off action, without feedback) OFF, 0.1 ... 80.0 <Default=0.1>	For measuring range without decimal point

	OFF, 0.01 ... 8.00 <Default=0.01 >	For measuring range with decimal point

5.2.10.3.2 Cooling Control Parameters

Cooling Control parameter	This menu is only available if configurations Cooling oder Heating-Cooling is selected. Depending on the configuration, particular parameters are not visible.	
P (xp)	see 5.2.10.3.1	
D (tv)		
I (tn)		
Cycle-time		
Max. Output ratio		
Hysteresis		
Deadband	Switching point distance "heating" and "cooling" This parameter is available for "heating and cooling" operations only. (Configuration Heating-Cooling = Heating-Cooling)	
	OFF, 0.1 ... 80.0 <Default=0.1 >	For measuring range without decimal point
	OFF, 0.01 ... 8.00 <Default=0.01 >	For measuring range with decimal point

5.2.10.4 Ramps

Ramp 1.0K/min / 0.1K/min	
<p>A programmed ramp is always activated when the setpoint is changed or when the mains supply is switched on. The ramp starts at the actual process value and ends at the pre-selected setpoint. The ramp can be activated for both setpoint 1 and setpoint 2. By programming the second setpoint a setpoint profile can be obtained, accordingly (see example with external contact In_1 (K1) below).</p>	

Ramp rising	OFF<Default>, 0.1 ... 99,9	°K/min for measurement range without decimal point
	OFF<Default>, 0.01 ... 9.99	°K/min for measurement range with decimal point
Ramp falling	OFF<Default>, 0.1 ... 99,9	°K/min for measurement range without decimal point
	OFF<Default>, 0.01 ... 9.99	°K/min for measurement range with decimal point

5.2.10.5 Cool down temperature

Cool down temperature <div style="background-color: black; color: white; padding: 2px; text-align: center; margin-top: 5px;">50°C</div>	Function „cooling and off“ described in 5.2.3 will be shut off when this temperature is attained.
---	---

5.2.10.6 Maximal filling time

Maximal Filling time <div style="background-color: black; color: white; padding: 2px; text-align: center; margin-top: 5px;">120s</div>	If the filling process lasts longer than the maximal filling time the alarm signal (monitoring signal) is activated.
--	--

5.2.10.7 Drainage time

Drainage time <div style="background-color: black; color: white; padding: 2px; text-align: center; margin-top: 5px;">20s</div>	This time is applied to the function „Drainage“ described in 5.2.3.
--	---

5.2.10.8 Offsets and setpoint limits

Offsets and setpoint limits	<p>By means of this menu the following parameters are adjustable:</p> <ul style="list-style-type: none"> • minimal setpoint supported by menu • maximal setpoint supported by menu • offset to be added to supply (forward circulation) temperature reading • offset to be added to return (return circulation) temperature reading • offset to be added to externally measured temperature reading
------------------------------------	--

5.2.11 Menue „System“


Main/System S10	<div style="display: flex; justify-content: space-between; align-items: center;"> ← <div style="display: flex; gap: 10px;"> <div style="background-color: #0070C0; color: white; padding: 5px 10px; border: 1px solid black;">Common</div> <div style="background-color: #0070C0; color: white; padding: 5px 10px; border: 1px solid black;">Field bus USB / LAN</div> </div> </div> <div style="background-color: #0070C0; color: white; padding: 5px 10px; border: 1px solid black; margin-top: 5px; text-align: center;">About</div> <div style="background-color: #0070C0; color: white; padding: 5px 10px; border: 1px solid black; margin-top: 5px; text-align: center;"> </div>	<p>This menu serves as access to general settings and informations listed in the following:</p>
---	---	---

5.2.11.1 Menu for Common Settings (General Settings)


Menue „Common“		
System/Settings S11		
←	Language English	Authorisation All parameters
	Time 19h:04min	Day / Month 14 / 7
	Year 2017	Sample rate 10 s
	Restart lock-out off	
Language	Deutsch (German) <Default>	German
	English (English)	English
Authorisation (LOC)	All Parameter adjustable <Default>	All parameters adjustable
	Setp. and ramps adjustable	Setpoints, alarm values and ramps are adjustable. All other parameters are locked.
	Only setpoint 1 adjustable	All other parameters are locked
	All parameters locked	No parameter is adjustable
	Change Lock code	Here the code (start value = 0000) can be changed to a different value.
<p>The previous code is requested before setting the new code. The new Code has to be entered twice. The parameters that have been locked can be displayed but not changed. This parameter cannot be changed if the logic input In_2 is active, or the lock code is not known. The value of the factory setting is <Default = 0000></p>		
Time	Hours	Number value 0 ... 23
	Minutes	Number value 0 ... 59

Day / Month	Day	Number value 1 ... 31
	Month	Number value 1 ... 12
Year	2000 ... 2150	Adjustment of calendar year
Sample rate Scanning time for recorder function	Time interval between the current measurements of two successive samples. In brackets the complete time interval as shown on display: 2,5 s (Total time: 8,2 Min) 5 s (Total time: 16,5 Min) 10 s (Total time: 33 Min) <Default> 30 s (Total time: 99 Min) 1 Min. (Total time: 3,3 h) 5 Min. (Total time: 16,5 h) 10 Min.(Total time: 33 h) A maximum of 198 temperature points can be saved.	
Restart lock-out	OFF <Default>	No function
	On	After power-on the temperature controlling is switched of and a message is displayed. Switch on must be acknowledged. After acknowledgement the controlling will be started. In addition the alarm "Restart lock-out" will be set and can be handled in the monitoring.


5.2.11.2 Menues Fieldbus / USB / LAN

		It depends on the installed field bus module what parameters will be visible.
Protocol	off	No protocol selected
	Elotech	<SERIAL> ELOTECH-Standard-protocol
	Modbus	<SERIAL> Modbus-RTU-protocol
	Arburg 1	<SERIAL> Hot runner
	Arburg 2	
	Arburg 3	<SERIAL> Protocol for temperature control systems
	Profibus DP	<PROFIBUS> Profibus DP
Status Display only	---	<SERIAL> No data communication
	Data Exchange	<SERIAL> Data communication is active <PROFIBUS> Data-Exchange-Mode
	Wait Param	<PROFIBUS> Controller waits for configuration / parametrisation
	No connection	<PROFIBUS> No master connected / Master not active

Baudrate <SERIAL>	1.2 kBaud	1.200 Bit/s
	2.4 kBaud	2.400 Bit/s
	4.8 kBaud	4.800 Bit/s
	9.6 kBaud	9.600 Bit/s
	19.2 kBaud <Default>	19.200 Bit/s
	38.4 kBaud	38.400 Bit/s
Baudrate <PROFIBUS>	Display only	45,5 kBaud – 12Mbaud (forced by the master) Not detected = no master connected
Address	1 ... 255	1 <Default> ... 255 (ELOTECH-Standard) 1 <Default> ... 247 (Modbus-RTU-Protocol) 1 <Default> ... 32 (Arburg-Protocols) 2 <Default> ... 125 (Profibus) At this address a master communicates with the controller. Each controller needs a unique address.
Format <SERIAL>	7 E 1 <Default>	7 Data bits, 1 Stop bit, Parity Even
	7 O 1	7 Data bits, 1 Stop bit, Parity Odd
	7 E 2	7 Data bits, 2 Stop bits, Parity Even
	7 O 2	7 Data bits, 2 Stop bits, Parity Odd
	7 N 2	7 Data bits, 2 Stop bits, Parity None
	8 E 1	8 Data bits, 1 Stop bit, Parity Even
	8 O 1	8 Data bits, 1 Stop bit, Parity Odd
	8 N 1	8 Data bits, 1 Stop bit, Parity None
	8 N 2	8 Data bits, 2 Stop bits, Parity None
HW-config <SERIAL>	The serial fieldbus module has three integrated interfaces. Select here the desired interface:	
	RS232/RS485	Signals see connection diagram.
	TTY	Signals see connection diagram.
Remote <PROFIBUS>	On	Profibus can read and write. Local operation is locked.
	Off <Default>	Profibus can read only. Local operation is permitted.


Menue "USB"		Save controller data on an USB-Stick. (USB-flash drive)
		The data is stored as a text file in an adjustable CSV-format. The USB-flash-drive must be formatted with FAT. (FAT16/ FAT32) The file name contains the last 5 digits "xxxxx" of the MAC-ID.
Save to USB	All parameters	Save all parameters Generates the file -> LogParaxxxx.txt and LogPara.bin

	Al. Logbook	Save the entries of the Alarm Logbook. Generates the file -> LogBookxxxxx.txt
	Graph	Save the readings of the graph Generates the file -> LogGraphxxxxx.txt
USB status	- - -	Display of the USB-status: no stick detected.
	Key detected	USB-stick detected: Files can be saved or loaded from the USB flash drive.
Load	Load all Parameters	Loading a previously saved parameter set. The file "LogPara.bin" must exist on the USB flash drive.
Separator	none <Default >	Delimiter symbol between single data sets: Spaces
	comma	,
	semicolon	;
	colon	:
	tabulator	<TAB>
Sample-Interval	OFF; <Default > 5...720s	Cycle time for writing an output line with time stamp on the USB stick. The values setpoint, actual value, output ratio and current actual value are written out.
<p>If the parameter "Log interval" is set to a numerical value, so a file named "LogR4000_xxxxx_YYYY_MM_DD.txt" is generated on the USB stick. "xxxxx" the last 5 digits of the MAC-ID. YYYY, MM and DD mean the year, month, day. After a change of date a new file is created.</p> <p>With the included names MAC-ID "xxxxx", the files can be assigned to different R4000 controllers.</p> <p>Each "Log interval" time a new row is added. The line includes a time-stamp, setpoint, the actual value, the output ratio and the actual current value.</p>		

<p>Menue "LAN"</p> 	<p>Ethernet interface for connection to</p> <ul style="list-style-type: none"> • Webbrowser • configuration tool EloVision 3 • PLC via MODBUS-TCP <p>Connect the device R4100 to the LAN.</p> <p>The static IP address must be set to an address which is not allocated to another device being part of the same LAN.</p> <p>Please adjust as well the subnet mask and the default gateway according to the requirements of the LAN.</p> <p>In order to operate the device via webbrowser please enter the choosen static IP adress into the address field of the webbrowser, for example: „192.168.100.100“</p>
--	---

Static IP address		192 . 168 . 100 . 100 Part 1 <Default>
		192 . 168 . 100 . 100 Part 2 <Default>
		192 . 168 . 100 . 100 Part 3 <Default>
		192 . 168 . 100 . 100 Part 4 <Default>
Subnet mask		
Subnet mask 1		255 . 255 . 255 . 0 Part 1 <Default>
Subnet mask 2		255 . 255 . 255 . 0 Part 2 <Default>
Subnet mask 3		255 . 255 . 255 . 0 Part 3 <Default>
Subnet mask 4		255 . 255 . 255 . 0 Part 4 <Default>
Default gateway		
def.-gateway 1		192 . 168 . 100 . 1 Part 1 <Default>
def.-gateway 2		192 . 168 . 100 . 1 Part 2 <Default>
def.-gateway 3		192 . 168 . 100 . 1 Part 3 <Default>
def.-gateway 4		192 . 168 . 100 . 1 Part 4 <Default>
MAC ID	549A11:5xxxxx	Display of the MAC-ID: 54:9A:11:5x:xx:xx
LAN connection	online / offline	For connection to other devices this parameter must be set to "online"

5.2.11.3 About

	
Firmware	Displays the current firmware version
Language version	Displays the current language version
Firmware update	<p>Start the firmware update by selecting the button "Start Update" and confirm with SAVE. A confirmation prompt opens. If this window is confirmed with YES, the unit turns into the loader mode.</p> <p>When the loader mode is accidentally turned on, you can switch back by a mains reset into the existing user program.</p>

	<p>If an update should be performed, a USB flash drive must be plugged in with the new firmware. After a short time the firmware folder appears in the line "Folder". E.g. „EL4100.01_V20xx_xx.ELO".</p> <p>Now you can start the loading process by touching the touch screen.</p> <p>The controller must not be disconnected from the power supply until the download is complete!</p> <p>After finished loading the new user program is started by a power interruption.</p>
Factory setting	Reset to factory delivery status. With the help of this parameter, all settings are deleted and reset to the delivery status. Choose "Reset", then press "SAVE" .
Type R4100-0x-x-000-0x-5	Type key of the controller
Firmware	Currently installed firmware version

6 Error Messages

Error message	Cause	Possible remedy
At actual process value maximum value flashes	Top range end has been exceeded, sensor defect	Check sensor and cable
At actual process value minimum value flashes	Bottom range end has been exceeded, sensor defect	Check sensor cable Check process value offset TC connected with inverted polarity
REMOTE: Parameter locked	Adjusting of parameters is not allowed. Device is controlled by fieldbus	Profibus: The parameter "Remote" in the menu Field bus is set to "on". The configuration-tool Elovision is active.
Field bus module unavailable		The controller is not fitted with the correct hardware for the selected protocol.
DfErr	Text display error	Please send the controller back to the manufacturer.
ERR0	System error	Please send the controller back to the manufacturer.
ERR8	System error	Quit error message. Check the parameters. If the error is still there, send the controller back to the manufacturer.

7 Technical Data

Input Pt100 / RTD -30....400°C	PT100-1 and PT100-2: 2- wire connection PT100-3 : 3- wire connection Built-in protection against sensor breakage and short circuit Sensor current: < 1 mA Calibration accuracy: ... < 0,2 % Linear error: < 0,2 % Influence of the ambient temperature: < 0,01 % / K	
Logic input	Internal resistance > 22k-Ohm Level 0 < 2V Level 1 > 9V; max 30V	
Logic outputs	Bist. voltage, 0/24 V DC, max. 500 mA, short-circuit proof	
Relay output	Relay changeover contact ; max. 250V AC, max. 3A, resistive load	
Continuous outputs	0...20 mA maximal load 300 Ohm; 0...10V minimal Load 5kOhm. Automatic switching, depending on connected load.	
Hybrid Output	Optional plug-in module tri-phase contacts, two phases are operated by controller. max. 440V AC; max. 13A ; max. 9kW total power Please note: These outputs have to be protected by seperate 16 Ampere fuses of type FF (very fast acting).	
Fieldbus	Optional plug-in module: - Serial: RS232, RS485, TTY (20mA) - Profibus DP, according to EN 50170 All variants are equipped with optical insulation.	
Ethernet	Modbus TCP	
USB	Host for USB-Stick; max. 100mA	
Supply voltage	24 V DC, +/-25 %	
Power consumption	appr. 6W + Power of logic outputs	
LCD-Display	8,8 cm (3,5") RGB-display with LED-backlight. 320 x 240 pixel with resistive Touch-Panel	
Data protection	EARAM, Semiconductor storage When using a Fieldbus interface please note: Permissible writing operations per parameter must not exceed 1 000 000.	
Real time clock	Backup battery: Lithium CR2032	
Housing R4100-C	Type	Unsealed frame to be covered by a front film
	Format	Ca. 90 x 90 mm; Mounting depth: ca.60 mm
	display cut-out	78 +0,5 mm x 70 +0,5 mm
	Material:	Sheet steel and Makrolon UL 94-V1
	Protection class	IP 10 (DIN 40050), Front side: IP 00
Housing R4100-M	Type	to be mounted on cap rail TS35/7,5
	Format	Width: ca. 130 mm Length: ca. 90 mm Heght: ca. 70 mm

	Material:	PVC
	Protection class	IP 10 (DIN 40050), Front side: IP 00
Weight R4100-C	Approximately 250 g, depending on actual model	
Weight R4100-M	Approximately 250 g, depending on actual model	
Connectors	Service-Interface: Ethernet RJ45 USB-Interface: Type A Profibus: SUB-D 9 Others: Screw terminals, Protection mode IP 10 (DIN 40050) Insulation class C	
Permissible operating conditions	Operating temperature:	0...50°C / 32...122°F
	Storage temperature:	-30...70°C / -22...158°F
	Climate class:	KWF DIN 40040; equivalent to annual average max. 75% rel. humidity, no condensation
Harmonized standards	EN 61326-1:2013 / EN 61000-3-2:2006+A1:2009+A2:2009 EN 61000-3-3:1995+A1:2001+A2:2005 Electrical safety: EN 61010-1	

Subject to changes without notification